

RS232 Mode Parameters

A> Set Up BAUD Rate
1200



4800



19200



B> Set Up Data Bits
7 Data Bits



C> Set Up Stop Bits
<1 Bit>



D> Set Up Parity
<None>



Odd



Space



E> Handshaking
RTS/CTS Enable



ACK/NAK Enable



XON/XOFF Enable



2400



<9600>



38400



<8 Data Bits>



2 Bits



Even



Mark



<RTS/CTS Disable>



<ACK/NAK Disable>



<XON/XOFF Disable>



Language Selection

<US English>



Italian



French



Swedish



Hungarian



Belgium



Denmark



Turkey



UK English



Spanish



German



Switzerland



Japanese



Portuguese



Netherlands



Scanning Line Selection for Multi Parallel lines modes

Multiple Parallel Lines Only



Single Line Only



<Double Click to Interchange
Multi Parallel / Single line>



Specifications subject to change without notice.



0145-85E00N1_V05



Easy & Powerful

PROGRAMMING

QUICK GUIDE


Configuration Flow Chart

① Scan Start of Configuration.



Start Configuration

② Scan all necessary labels for parameters that meet applications.





Interface Selection
RS232 Mode Parameters
Reading Mode Selection
Symbolgies Selection

③ Scan End of Configuration to end the programming.

End Configuration

④ To permanently save the settings by your programmed, just scan label for Save Parameters.

Save Parameters

Set All Defaults



%\$+/ 2

Interface Selection
<Keyboard>



%0U0

USB



%0X08

Reading Mode Selection
<Good Read OFF>



%0271

Continuous/Trigger OFF



%0272

Continuous/Auto Power On



%0273

Flash/Auto Power On



%0276

Select Terminator
<CR+LF>



%7S2+

CR



%7S0+

Space



%7S4+

STX-ETX



%7S5+

Version Information



%\$+/ 5

RS232



%0U8

Virtual COM (Option)



%0088

Trigger ON/OFF



%0270

Testing



%0275

Flash



%0274

Presentation (Option)



%09F8

None



%7S7+

LF



%7S1+

HT(TAB)



%7S3+

Symbolgies Selection

UPC-A <ON>



%0A44

UPC-E <ON>



%0B08

EAN-13/JAN-13/ISBN-13 <ON>



%0A22

EAN-8/JAN-8 <ON>



%0A11

CODE 39 <ON>



%0E08

CODE 128 <ON>



%0F08

CODABAR/NW7 <ON>



%0J08

Interleaved 2 of 5 <ON>



%0G08

CODE 93 ON



%0K08

China Postage ON



%0M08

Telepen ON



%0T08

GS1 DataBar Omnidirectional ON



%0U08

GS1 DataBar Limited ON



%0V08

GS1 DataBar Expanded ON



%0W08

Select All Bar Codes



%1A/ +

UPC-A OFF



%0A40

UPC-E OFF



%0B00

EAN-13/JAN-13/ISBN-13 OFF



%0A20

EAN-8/JAN-8 OFF



%0A10

CODE 39 OFF



%0E00

CODE 128 OFF



%0F00

CODABAR/NW7 OFF



%0J00

Interleaved 2 of 5 OFF



%0G00

CODE 93 <OFF>



%0K00

China Postage <OFF>



%0M00

Telepen <OFF>



%0T00

GS1 DataBar Omnidirectional <OFF>



%0U00

GS1 DataBar Limited <OFF>



%0V00

GS1 DataBar Expanded <OFF>



%0W00